EF708-701

EF708 Spare parts exploded views



序号	零件	规格号	用量	备注
7	Whisk		1	
6	Dough hook		1	
5	Beater		1	
4	S.S Bowl		1	
3	Transparent splash guard		1	
2	funnel		1	
1.33	Middle cover			
1.32	power line		1	
1.31	heat-shrinkable tubing		1	
1.30	Nylon cable ties		6	
1.29	Motor connection		1	
1.28	Hall connection		1	
1.27	Ground wire A of Model EF708		1	
1.26	Ground wire B of Model EF708		1	
1.25	Ground wire C of Model EF708		1	
1.24	Bottom cover		1	
1.23	safety switch assembly		1	
1.22	Preset timer		1	
1.21	PCB		1	
1.20	Switch knob assembly		1	
1.19	Bowl Seat		1	
1.18	screw		3	
1.17	Bottom assembly		1	
1.16	Main shaft screw		1	
1.15	Spring washer		1	
1.14	flat gasket		1	
1.13	Planetary wheel assembly		1	
1.12	Toper cover assembly		1	
1.11	Motor assembly		1	
1.10	screw		4	
1.9	Gear Box assembly		1	
1.8	Accessory baffle assembly		1	
1.7	Motor cover		1	
1.6	Round screw		4	
1.5	screw		6	
1.4	Top cover assembly		1	
1.3	Flat screw		5	
1.2	screw		21	
1.1	Front Cover assembly		1	
1	Whole Machine			

标记	处数	分区	更改文件号	签 名	日 期
设 计			标准化		
校 对					
审 核					
工 艺					

阶段标记	重量(g)	比例
A		FREE
共 1 张	第 1 张	

伊丝顿 EASTEN 电器有限公司

708爆炸图

EF708-701